

hop on stroller platform - fitting guide

Before you purchase the hop on stroller platform please check the compatibility guide (link on the product detail page) to find out if it is compatible with your pushchair or stroller.

Below are general fitting instructions, however please ensure you use these in conjunction with the specific fitting guide for your pushchair in the table below.

<p>Arm fixing point:</p>	<p>Refer to fitting guide for your pushchair, to see correct arm fixing point (positions 1, 2 or 3).</p>	<p>Slide the arms on either side of the board, align the appropriate holes as indicated and secure with the screw.</p>	
<p>Pushchair component fitted to:</p>	<p>Refer to fitting guide for your pushchair, to see which component of the pushchair you should attach to.</p>	<p>Undo the screw on the clamp and remove the wedge. Wrap the strap around the indicated component and refasten by pulling the strap tight then reassemble the wedge and tighten the screw.</p>	
<p>Height of fixing point:</p>	<p>Refer to fitting guide for your pushchair, to see correct height of fixing in mm.</p>	<p>Check the position of the clamp by measuring from the floor to the center of the screw.</p>	
<p>Board width:</p>	<p>Refer to fitting guide for your pushchair, to see correct board width (positions available; closed-6).</p>	<p>Undo the screw underneath the board and adjust the width as indicated. Retighten the screw underneath to fix in place.</p>	
<p>Arm angle:</p>	<p>Refer to fitting guide for your pushchair, to see correct arm angle (positions available; 1-7).</p>	<p>Loosen the screws on either side, slide the arms out and adjust the angle to the position indicated. Push the arms towards the board to locate them and retighten the screws.</p>	
<p>Ball joint orientation:</p>	<p>Refer to fitting guide for your pushchair, to see correct ball joint orientation (positions 1, 2, 3 or 4).</p>	<p>Undo the screw holding the ball joint in place using a coin or flat blade screw driver. Remove the joint and reposition as indicated. Secure in place using the screw.</p>	

Continue for specific pushchair fitting instructions.

Please refer to the below table for correct fitting settings for your make and model of pushchair or stroller.

Brand	Model	Arm fixing point (1-3)	Pushchair component fitted to:	Height of fixing point (mm)	Board width (closed - 6)	Arm angle (1-7)	Ball joint orientation (1,2,3,4)	Notes
Baby Jogger	City Mini	1	Rear leg	300	6	3	1	
Baby Jogger	City Mini Twin	1	Rear crossbar	200	Closed	5	3	
Baby Style	Oyster	1	Rear leg	320	Closed	3	3	Access to brake restricted
Britax	B-Dual 4	n/a	n/a	n/a	n/a	n/a	n/a	No fit, use 2nd seat
Britax	B-Smart 3	1	Axle	n/a	Closed	7	1	
Britax	Vigour	1	Rear leg	260	Closed	4	3	
Bugaboo	Bee	1	Rear leg	340	6	3	1	
Bugaboo	Cameleon	1	Axle	n/a	Closed	6	2	
Chicco	Ct0.6	1	Rear leg	175	6	6	2	
Chicco	Lite Way	1	Rear leg	300	5	4	2	
Chicco	Multiway	1	Rear leg	415	6	1	1	
Combi	We 2	1	Rear leg	190	2	5	1	Left or right hand fitting
Concorde	Neo Quantum	n/a	n/a	n/a	n/a	n/a	n/a	No fit
Cosatto	Yo	3	Rear leg	355	6	3	1	
Easywalker	Duo	n/a	n/a	n/a	n/a	n/a	n/a	No fit
Graco	Mosaic	3	Rear leg	315	6	4	1	
Jane	Powertwin Pro	1	Rear leg	265	Closed	4	3	
Joovy	Caboose	1	Lower handle	410	6	2	1	
Maclaren	Grand Tour LX	1	Rear leg	160	1	2	3	Cannot be fully folded
Maclaren	Juicy Couture	2	Rear leg	290	6	4	2	
Maclaren	Cath Kidston	2	Rear leg	380	5	4	2	
Maclaren	Quest Sport	2	Rear leg	380	5	4	2	
Maclaren	Techno XLR	1	Rear leg	410	6	3	2	
Maclaren	Techno XT	2	Rear leg	290	6	4	2	
Maclaren	Triumph	1	Rear leg	280	4	4	1	
Maclaren	Twin Techno	3	Rear leg	350	3	3	1	Left side only (viewed from the back)
Maclaren	Twin Triumph	3	Rear leg	320	3	3	1	Left side only (viewed from the back)
Maxi Cosi by Bebeconfort	Loola	2	Rear leg	310	Closed	4	3	
Maxi Cosi by Bebeconfort	Loola Up	2	Rear leg	310	Closed	4	3	
Maxi Cosi	Mila	3	Rear leg	265	Closed	4	3	
Mothercare	Baby K	3	Rear leg	285	4	4	2	
Mothercare	Backspin	2	Rear leg	300	5	3	2	
Mothercare	Backspin Plus	1	Rear leg	360	5	3	1	Be aware of the increased risk of backward tipping

Continued...

Brand	Model	Arm fixing point (1-3)	Pushchair component fitted to:	Height of fixing point (mm)	Board width (closed - 6)	Arm angle (1-7)	Ball joint orientation (1,2,3,4)	Notes
Mothercare	Curv	3	Rear leg	315	6	4	1	
Mothercare	Duolite	1	Rear crossbar	n/a	4	5	4	Basket lifted slightly
Mothercare	Flyte	2	Rear leg	350	6	3	1	
Mothercare	Hoxton	2	Rear leg	330	6	3	1	
Mothercare	Jive	3	Rear leg	285	4	4	2	
Mothercare	M-Bu	3	Rear leg	185	3	5	1	
Mothercare	M-Bu Twin	3	Rear leg	300	3	4	1	
Mothercare	MPV	3	Rear leg	300	3	4	1	Left side only (viewed from the back)
Mothercare	My Choice 3 Wheeler	1	Rear leg	320	Closed	3	3	
Mothercare	My Choice 4 Wheeler	1	Rear leg	320	Closed	3	3	
Mothercare	Nulo	1	Rear leg	245	5	5	2	Access to brake restricted
Mothercare	Phoenix	2	Rear leg	310	6	4	1	
Mothercare	Pick & Mix	1	Rear leg	330	6	3	2	
Mothercare	Spin	1	Rear leg	260	Closed	4	3	
Mothercare	Swoop	1	Rear leg	260	6	4	1	
Mothercare	Trenton Deluxe	1	Rear leg	190	6	5	1	Head room for child restricted
Mothercare	U Move	1	Rear leg	290	6	4	1	
Mothercare	Ultimate Collection	1	Rear leg	320	6	3	2	
Mothercare	Urbanite	1	Rear leg	410	4	1	1	
Mothercare	Valday	3	U shaped tube	225	0	5	3	Chassis fixing must be angled outwards
Mothercare	Vesta	1	Rear leg	230	6	5	1	
Mothercare	Vesta Twin	1	Axle	n/a	Closed	6	4	
Mothercare	Vio	1	Lower horizontal bar	n/a	6	6	2	
Mothercare	Whizzi	2	Rear leg	280	5	4	2	
Mothercare	Xcursion	1	Rear leg	380	2	2	3	
Mothercare	Xoob	1	Rear leg	245	5	5	2	Access to brake restricted
Mothercare	Xoob2	3	Rear leg	355	5	3	1	Must be fitted behind the left seat.
Mothercare	Xtreme	1	Rear leg	340	6	3	1	
Obaby	Atlas	1	Rear leg	300	5	4	2	
Obaby	Atlas Sport	1	Rear leg	300	5	4	2	
Petite Star	Zia 3	1	Lower horizontal bar	n/a	6	6	2	

Continued...

